

Industrial Device Server User's Manual

IDS-141A / IDS-181A



Version 1.00
December 2009.



ORing Industrial Networking Corp.

3F., No.542-2, Jhong-Jheng Rd., Sindian

District, New Taipei City 231- 48, Taiwan,

R.O.C.

Tel: + 886 2 2218 1066

Fax: + 886 2 2218 1014

Website : www.oring-networking.com

E-mail : support@oring-networking.com

Table of Content

| | |
|---|-----------|
| GETTING TO KNOW YOUR DEVICE SERVER | 1 |
| 1.1 <i>About the IDS-141A / IDS-181A Serial Device Server</i> | 1 |
| 1.2 <i>Software Features</i> | 1 |
| 1.3 <i>Hardware Features</i> | 2 |
| HARDWARE INSTALLATION | 3 |
| 2.1 <i>Install IDS-141A / IDS-181A on DIN-Rail</i> | 3 |
| 2.1.1 Mount IDS-141A / IDS-181A on DIN-Rail | 3 |
| 2.2 <i>Wall Mounting Installation</i> | 4 |
| 2.2.1 Mount IDS-141A / IDS-181A on wall | 5 |
| HARDWARE OVERVIEW | 7 |
| 3.1 <i>Front Panel</i> | 7 |
| 3.2 <i>Front Panel LEDs</i> | 8 |
| 3.3 <i>Serial Ports</i> | 8 |
| 3.4 <i>Bottom Panel</i> | 10 |
| CABLES | 11 |
| 4.1 <i>Ethernet Cables</i> | 11 |
| MANAGEMENT INTERFACE | 13 |
| 5.1 <i>DS-Tool</i> | 13 |
| 5.1.1 Install DS-Tool | 13 |
| 5.1.2 Using DS-Tool | 15 |
| 5.1.2.1 Explore device servers | 15 |
| 5.1.2.2 Configure device servers | 16 |
| 5.1.2.3 Configure serial port | 25 |
| 5.2 <i>Configuration by Web Browser</i> | 34 |
| 5.2.1 Connect to the Web page | 34 |
| 5.2.1.1 System | 36 |
| 5.2.1.2 Port serial setting | 40 |
| 5.2.1.3 Management | 48 |
| 5.2.1.4 Save/Reboot | 52 |



| | | |
|---------------------------------------|---|-----------|
| 5.3 | <i>Configuration by SSH Console</i> | 53 |
| 5.3.1 | Connect to DS..... | 53 |
| TECHNICAL SPECIFICATIONS | | 54 |

Getting to Know Your Device Server

1.1 About the IDS-141A / IDS-181A Serial Device Server



IDS-141A / IDS-181A is an innovative 4 & 8 ports RS232 to LAN device server. Users are able to configure IDS-141A / IDS-181A by DS-Tool via LAN port. IDS-141A / IDS-181A offers many powerful features for HW & SW redundant functions.

IDS-141A / IDS-181A can simultaneously transfer data into 5 host PCs. This feature can assure all critical data that saved in different host PCs to avoid Ethernet break or host PCs failure.

Secondly, the IDS-141A / IDS-181A provides dual redundant power inputs on terminal block. IDS-141A / IDS-181A also provides NAT pass through function so that users are able to manage IDS-141A / IDS-181A inside or outside the NAT router. It is easy for different IP domain users to use IDS-141A / IDS-181A. Therefore, IDS-141A / IDS-181A is the best communication redundant solution for current application of serial devices.

1.2 Software Features

- NAT-pass through: User can manage IDS-141A / IDS-181A through NAT router.
- Redundant Power Inputs: 12~48VDC on terminal block. & power jack
- Redundant multiple host devices: 5 simultaneous in Virtual COM, TCP Server, TCP Client mode, and 4 simultaneous for UDP mode.
- Secured Management by HTTPS and SSH.
- Versatile Modes: Virtual Com, Serial Tunnel, TCP Server, TCP Client, UDP
- Event Warning by Syslog, Email, SNMP trap, Relay
- Various Windows O.S. supported: Windows NT/2000/ XP/ 2003/VISTA 32bits



1.3 Hardware Features

- Redundant Power Inputs: 12~48 VDC on terminal block and power jack
- Operating Temperature: -40 to 70°C
- Storage Temperature: -40 to 85 °C
- Operating Humidity: 5% to 95%, non-condensing
- Casing: IP-30
- One 10/100Base-T(X) Ethernet port
- Dimensions(W x D x H) : 26.1(W) x 94.9(D) x 144.3(H) mm

Hardware Installation

2.1 Install IDS-141A / IDS-181A on DIN-Rail

Each IDS-141A / IDS-181A has a Din-Rail kit on rear panel. The Din-Rail kit helps IDS-141A / IDS-181A to fix on the Din-Rail. It is easy to install the IDS-141A / IDS-181A on the Din-Rail:

2.1.1 Mount IDS-141A / IDS-181A on DIN-Rail

Step 1: Slant the IDS-141A / IDS-181A and mount the metal spring to Din-Rail.




Figure 2-1

Step 2: Push the IDS-141A / IDS-181A toward the Din-Rail until you heard a “click” sound.



Figure 2-2

2.2 Wall Mounting Installation

Each IDS-141A / IDS-181A has another installation method for you. A wall mount panel can be found in the package. The following steps show how to mount the IDS-141A / IDS-181A on the wall:

2.2.1 Mount IDS-141A / IDS-181A on wall

Step 1: Remove Din-Rail kit.




Figure 2-3

Step 2: Use 6 screws that can be found in the package to combine the wall mount panel.
Just like the picture shows below:



Figure 2-4

The screws specification shows in the following two pictures. In order to prevent IDS-141A / IDS-181A from any damage, the size of screws should not be larger than the size that used in IDS-141A / IDS-181A.




Figure 2-5

Hardware Overview

3.1 Front Panel




Figure 3-1

1. LED for PWR1 and system status. When the PWR1 links, the green LED will be light on.
2. LED for PWR2 and system status. When the PWR2 links, the green LED will be light on.
3. LED for fault indicator. When fault occurred, this red LED will be light on.
4. LED for Serial ports status. When data transmitted, the green LED will be light on. (S5~S8 only available for IDS-181A)
5. LED for Serial ports status. When data transmitted, the green LED will be light on. (S5~S8



only available for IDS-181A)

6. DB62 Female port.
7. Reset button, press for 10 sec for factory default.
8. 10/100Base-T(X) Ethernet port

3.2 Front Panel LEDS


The following table describes the labels that stick on the IDS-141A / IDS-181A.

| LED | Color | Status | Description |
|---------|-------------|-------------------------|---|
| PWR1 | Green | On | DC power 1 activated. |
| | | Blinking | System Booting / Located by administrator |
| PWR2 | Green | On | DC power 2 activated. |
| | | Blinking | System Booting / Located by administrator |
| Fault | Amber | On | Fault event occurred. |
| S1 ~ S8 | Green | Blinking | Serial port is transmitting/receiving data(S5~S8 only available for IDS-181A) |
| ETH | Green/Amber | Green/Amber On/Blinking | 100Mbps LNK/ACT |
| | | Green On/Blinking | 10Mbps LNK/ACT |

Table 3-1 Front panel LEDS

3.3 Serial Ports

There 8 serial ports on the front panel of IDS-141A / IDS-181A shown as below:



| Pin # | RS 232 | Pin # | RS 232 |
|-------|--------|-------|--------|
| 1 | TXD1 | 32 | GND |
| 2 | DTR1 | 33 | TXD5 |
| 3 | RXD2 | 34 | DTR5 |
| 4 | DSR2 | 35 | RXD6 |
| 5 | DCD2 | 36 | DSR6 |
| 6 | TXD3 | 37 | DCD6 |
| 7 | DTR3 | 38 | Txd7 |
| 8 | RXD4 | 39 | DTR7 |
| 9 | DSR4 | 40 | GND |
| 10 | DCD4 | 41 | TXD8 |
| 11 | RXD5 | 42 | DTR8 |
| 12 | DSR5 | 43 | CTS1 |
| 13 | DCD5 | 44 | RTS1 |
| 14 | TXD6 | 45 | GND |
| 15 | DTR6 | 46 | CTS2 |
| 16 | RXD7 | 47 | RTS2 |
| 17 | DSR7 | 48 | CTS3 |
| 18 | DCD7 | 49 | RTS3 |
| 19 | RXD8 | 50 | GND |
| 20 | DSR8 | 51 | CTS4 |
| 21 | DCD8 | 52 | RTS4 |
| 22 | RXD1 | 53 | CTS5 |
| 23 | DSR1 | 54 | RTS5 |
| 24 | DCD1 | 55 | GND |
| 25 | TXD2 | 56 | CTS6 |
| 26 | DTR2 | 57 | RTS6 |
| 27 | RXD3 | 58 | GND |
| 28 | DSR3 | 59 | CTS7 |
| 29 | DCD3 | 60 | RTS7 |
| 30 | TXD4 | 61 | CTS8 |
| 31 | DTR4 | 62 | RTS8 |

(S5~S8 only available for IDS-181A)

Table 3-2 Pin assignment

3.4 Bottom Panel

The bottom panel components of IUSB-9041 are shown as below:

1. Terminal block includes: PWR1 (12~48V DC).
2. Relay output (1A@24VDC).
3. Terminal block includes: PWR2 (12~48V DC).
4. Power Jack include: PWR2 (12 ~ 48V DC).
5. Frame ground.




Figure 3-2



Cables

4.1 Ethernet Cables

The IDS-141A / IDS-181A has standard Ethernet ports. According to the link type, the IDS-141A / IDS-181A use CAT 3, 4, 5, 5e UTP cables to connect to any other network device (PCs, servers, switches, routers, or hubs). Please refer to the following table for cable specifications.

| Cable | Type | Max. Length | Connector |
|------------|----------------------|--------------------|-----------|
| 10BASE-T | Cat. 3, 4, 5 100-ohm | UTP 100 m (328 ft) | RJ-45 |
| 100BASE-TX | Cat. 5 100-ohm UTP | UTP 100 m (328 ft) | RJ-45 |

Table 4-1 Cable Types and Specifications

100BASE-TX/10BASE-T Pin Assignments

With 100BASE-TX/10BASE-T cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 are used for receiving data.



| Pin Number | Assignment |
|------------|------------|
| 1 | TD+ |
| 2 | TD- |
| 3 | RD+ |
| 4 | Not used |
| 5 | Not used |
| 6 | RD- |
| 7 | Not used |
| 8 | Not used |

Table 4-2 RJ-45 Pin Assignments

The IDS-141A / IDS-181A supports auto MDI/MDI-X operation. You can use a straight-through cable to connect PC to IDS-141A / IDS-181A. The following table below shows the 10BASE-T/ 100BASE-TX MDI and MDI-X port pin outs.

| Pin Number | MDI port | MDI-X port |
|------------|---------------|---------------|
| 1 | TD+(transmit) | RD+(receive) |
| 2 | TD-(transmit) | RD-(receive) |
| 3 | RD+(receive) | TD+(transmit) |
| 4 | Not used | Not used |
| 5 | Not used | Not used |
| 6 | RD-(receive) | TD-(transmit) |
| 7 | Not used | Not used |
| 8 | Not used | Not used |

Table 4-2 MDI / MDI-X pins assignment

Note: "+" and "-" signs represent the polarity of the wires that make up each wire pair.

Management Interface

5.1 DS-Tool

DS-Tool is a powerful Windows utility for DS series. It supports device discovery, device configuration, group setup, group firmware update, monitoring functions...etc. It is easy for you to install and configure devices over the network.

5.1.1 Install IDS-Tool

Step 1: Execute the Setup program, click “**start**” after selecting the folder for DS-Tool.




Figure 5-1

Step 2: When installation complete successfully, then click "OK".




Figure 5-2

Step 3: Check for your selection.




Figure 5-3

5.1.2 Using DS-Tool

5.1.2.1 Explore device servers

DS-Tool will broadcast to the network and search all available DS devices in the network. The default IP address of device is “**192.168.10.2**”, and selects the searching device you wish to use and press “**Add**” button.

You can set static IP address or in DHCP client mode to get IP address automatically. Finally, click “**OK**” button to add the device.





Figure 5-4

5.1.2.2 Configure device servers

General settings

This page includes the setting of device name, SNTP server and Auto IP Report.



The screenshot displays the 'General settings' page for the IDS-181A device. The interface includes a navigation bar with tabs for General, Security, Networking, DDNS, Notification, Management, Upgrade Firmware, and Save/Load. The main content area shows the following settings:

- Model:** IDS-181A
- Power:** 1 (indicated by a green bar), 2 (indicated by a grey bar)
- LAN IP Address:** 192.168.10.2
- LAN MAC Address:** 00:32:13:21:31:31
- Version:** 1.00b
- Locate On:** A button with a location pin icon.
- Device Name/Location:** DeviceServer-DEFAULT
- Using SNTP Time Server:** Checked. Includes fields for SNTP Server IP (pool.ntp.org), Port (123), and Time Zone (GMT+08:00)Taipei.
- Auto IP Report:** Checked. Includes fields for IP Address (192.168.10.248), Port (60001), a Get Current Host button, and Report Interval (10 Seconds).

At the bottom of the page, there are buttons for Refresh, Apply Only, and Apply and Save.

Figure 5-5 General settings

The following table describes the labels in this screen.

| Label | Description |
|----------------------|---|
| Device Name/location | You can set the device name or related information. By clicking "Locate On" button you can locate the serial server's position. |
| Set SNTP | Input the SNTP server domain name or IP address, port and select the Time zone. |

| | |
|--------------------|--|
| Set Auto IP Report | By Clicking the “ Get current Host ” button you will get your local IP, and then set the Report interval time. The device server will report its status periodically. |
|--------------------|--|

Table 5-1 General settings

At IP collection option show the device server status. The report interval is 0 indicate disable this setting (default). But you can set the other IP or Port.

Security




Figure 5-6 Security

The following table describes the labels in this screen.

| Label | Description |
|-----------------------|---|
| Accessible IP Setting | To prevent unauthorized access by setting host IP addresses and network masks. |
| Password setting | You can set the password to prevent unauthorized access from your server. Factory default is no password. |

Table 5-2 Security

Network Setting

Device DS can connect the Network by wire a. You must assign a valid IP address for DS before attached in your network environment. Your network administrator should provide you the IP address and related settings. The IP address must be unique within the network (otherwise, DS will not have a valid connection to the network). You can choose from three possible “**IP configuration**” modes: Static, DHCP/BOOTP. The Factory Default IP address is “**192.168.10.2**”




Figure 5-7 Network Setting

The following table describes the labels in this screen.

| Label | Description |
|-------------------|---|
| Using DHCP/BOOTP | IP Address automatically assigned by a DHCP server in your network. |
| Static IP Address | Manually assigning an IP address. |
| Subnet Mask | All devices on the network must have the same subnet mask to communicate on the |

| | |
|------------|---|
| | network. |
| Gateway | Enter the IP address of the router in you network. |
| DNS Server | Enter the IP address of the DNS server, The DNS server translates domain names into IP address. |

Table 5-3 Network setting

PPPoE

PPPoE (Point-to-Point Protocol over Ethernet), Device can use PPPoE mode to connect the Network. Input the “**username**” and “**Password**”, then click “**Connect**” button. If the device has been connected, the “**Link Status**” will become the “Link up” and device will get an IP address from PPPoE server. Click “**Disconnect**” button to disconnect the PPPoE connection.





Figure 5-8 PPPoE Setting

DDNS

The Dynamic DNS service allows you to alias a dynamic IP address to a static hostname, allowing your computer to be more easily accessed from various locations on the Internet.



The screenshot shows the DDNS configuration page with the following elements:

- Navigation tabs: General, Security, Networking, **DDNS**, Notification, Management, Upgrade Firmware, Save/Load
- DDNS Enable: DDNS Enable
- DDNS Setting section:
 - Service Provider: ezip (dropdown menu)
 - Hostname: 0 (text input)
 - Account: 0 (text input)
 - Password: * (password input)
 - Check WAN IP Schedule: Every Hour (dropdown menu)
 - Start at: 0 (Hour) : 0 (Minute)
- Buttons at the bottom: Refresh, Apply Only, Apply and Save

Figure 5-8 DDNS Setting

The following table describes the labels in this screen.

| Label | Description |
|--------------------------|--|
| Service Provider | Choose the DDNS service Provider |
| Hostname | You must first apply an account from the DDNS service Provider such as www.dyndns.org, then register with the dynamic DNS service. Input the fixed hostname you got from the DDNS service. |
| Account mand Password | Input the Account and Password you have registered from the DDNS service Provider. |
| Check WAN IP Schedule | Device will check the IP address Status at interval time you set. |

Table 5-4 DDNS setting

Notification

Specify the events that should be notified to the administrator. The events can be alarmed by E-mail, SNMP trap, or system log.




Figure 5-9 Notification



The following table describes the labels in this screen.

| Label | Description |
|---------------------------|---|
| SNMP Trap | To notify events by SNMP trap. |
| Email Notification | To notify events by Email. |
| Syslog Notification | To notify events by Syslog. |
| Fault LED /Relay Settings | To notify events by Fault LED and relay.. |
| Notify items | Events to be notified. |
| Apply | Apply current setting. |
| Apply and Save | Apply and save current setting. |

Table 5-3 Notification

Management

General | Security | Networking | DDNS | Notification | Management | Upgrade Firmware | Save/Load

Web Management Enable Goto Web Management

Telnet Management Enable Goto Telnet Management

SNMP Management Enable

SNMP Management Settings:

Community

Location

Contact

Trap Server1

Trap Server2

Trap Server3

Trap Server4

Figure 5-10 Management

The following table describes the labels in this screen.

| Label | Description |
|--------------------------|---|
| Web Management Enable | To enable management from Web. Click " Goto Web Management " button to access web. |
| Telnet Management Enable | To enable management by Telnet. |
| SNMP Management Enable | To enable management by SNMP. |
| SNMP Management Settings | To configure SNMP related settings. |

Table 5-4 Management

Upgrade Firmware




Figure 5-11 Upgrade Firmware

The following table describes the labels in this screen.

| Label | Description |
|----------|------------------------------|
| Browsing | Browse the file and upgrade |
| Upgrade | Enable the firmware upgrade. |

Table 5-5 Upgrade Firmware

Save/Load




Figure 5-12 Save / Load

The following table describes the labels in this screen.

| Label | Description |
|-----------------------------|---|
| Save Configuration to Flash | Save current configuration into flash memory. |
| Load Default | Load default configuration except the network settings. If you want to load all factory default, you need to press “Reset” button on the device (Hardware restore). |
| Reboot Device | Reboot the device server (warm start). |
| Import Configuration | Restore the previous exported configuration. |
| Export Configuration | Exported current configuration to a file to backup the configuration. |

Table 5-6 Save / Load

5.1.2.3 Configure serial port

Serial Settings

Serial Settings | Service Mode | Notification

port1

Port Alias

Baudrate Stop Bits Performance

Parity Flow Control

Data Bits Interface

Delimiter Settings

Serial to Ethernet | Ethernet to Serial

Delimiter 1 (HEX) Enabled

Delimiter 2 (HEX) Enabled

Delimiter 3 (HEX) Enabled

Delimiter 4 (HEX) Enabled

Flush Serial to Ethernet Data Buffer After (0-65535) ms

The received data will be queueing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flush S2E data buffer" timeout, the data will also be sent.

Force TX interval time (0-65535) ms interval time interval time

The received data will be queueing in TX buffer until TX interval time is timeout or TX buffer is full (4K Bytes) , the data will also be sent. 0 is disable.

Figure 5-13 Serial Settings

The following table describes the labels in this screen.

| Label | Description |
|--------------|--|
| Port Alias | Remark the port to hint the connected device. |
| Interface | RS232 |
| Baud rate | 110bps/300bps/1200bps/2400bps/4800bps/9600bps/19200bps/ 38400bps/57600bps/115200bps |
| Data Bits | 5, 6, 7, 8 |
| Stop Bits | 1, 2 (1.5) |
| Parity | No, Even, Odd, Mark, Space |
| Flow Control | No, XON/XOFF, RTS/CTS, DTR/DSR |



| | |
|--------------------|--|
| Performance | <p>Throughput: This mode optimized for highest transmission speed.</p> <p>Latency: This mode optimized for shortest response time.</p> |
| Serial to Ethernet | <p>Delimiter:</p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option-"Flush Serial to Ethernet data buffer" times out. 0 means disable. Factory default is 0.</p> <p>Flush Data Buffer After:</p> <p>The received data will be queuing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flush S2E data buffer" timeout the data will also be sent. You can set the time from 0 to 65535 seconds.</p> |
| Ethernet to Serial | <p>Delimiter:</p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option "Flush Ethernet to Serial data buffer" times out. 0 means disable. Factory default is 0.</p> <p>Flush Data Buffer After:</p> <p>The received data will be queuing in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flushE2S data buffer" timeout the data will also be sent. You can set the time from 0 to 65535 seconds.</p> |

| | |
|------------------------|--|
| Force TX Interval Time | <p>Force TX interval time is to specify the timeout when no data has been transmitted.</p> <p>When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent.</p> <p>0 means disable. Factory default value is 0.</p> |
|------------------------|--|

Table 5-7 Serial settings

Service Mode – Virtual COM Mode

In Virtual COM Mode, The driver establishes a transparent connection between host and serial device by mapping the Port of the serial server serial port to local COM port on the host computer. Virtual COM Mode also supports up to 5 simultaneous connections, so that multiple hosts can send or receive data by the same serial device at the same time.




Figure 5-14 Virtual COM



The following table describes the labels in this screen.

| Label | Description |
|-----------------|---|
| Map Virtual COM | Select a Virtual COM Name to map on. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |

Table 5-8 Virtual COM

**Not allowed to mapping Virtual COM from web*

Service Mode – TCP Server Mode

In TCP Server Mode, DS is configured with a unique Port combination on a TCP/IP network. In this case, DS waits passively to be contacted by the device. After a connection is established, it can then proceed with data transmission. TCP Server mode also supports up to 5 simultaneous connections, so that multiple device can receive data from the same serial device at the same time.

Serial Settings | Service Mode | Notification

Service Mode: TCP Server Mode

TCP Server Mode

TCP Server Settings

Data Port: 4002

Control Port: 4003

Misc.

Idle Timeout: 0 (0-65535) Seconds

Alive Check: 0 (0-65535) Seconds

Multilink

Max Connections: 1

Destination Host

| | | | |
|---|----------------------|----------------------|---|
| 1 | <input type="text"/> | <input type="text"/> | <input type="button" value="Disconnect"/> |
| 2 | <input type="text"/> | <input type="text"/> | <input type="button" value="Disconnect"/> |
| 3 | <input type="text"/> | <input type="text"/> | <input type="button" value="Disconnect"/> |
| 4 | <input type="text"/> | <input type="text"/> | <input type="button" value="Disconnect"/> |
| 5 | <input type="text"/> | <input type="text"/> | <input type="button" value="Disconnect"/> |

Figure 5-15 TCP Server mode

The following table describes the labels in this screen.

| Label | Description |
|----------------|---|
| Data Port | Set the port number for data transmission. |
| Auto Scan | Scan the data port automatically. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |

Table 5-9 TCP Server mode



Service Mode – TCP Client Mode

In TCP Client Mode, device can establish a TCP connection with server by the method you have settled (Startup or any character). After the data has been transferred, device can disconnect automatically from the server by using the TCP alive check time or Idle time settings.




Figure 5-16 TCP Client mode

The following table describes the labels in this screen.

| Label | Description |
|------------------|-----------------------------------|
| Destination Host | Set the IP address of host. |
| Port | Set the port number of data port. |



| | |
|--------------------------|---|
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Connect on Startup | The TCP Client will build TCP connection once the connected serial device is started. |
| Connect on Any Character | The TCP Client will build TCP connection once the connected serial device starts to send data. |

Table 5-10 TCP Client mode

Service Mode – UDP Mode

Compared to TCP communication, UDP is faster and more efficient. In UDP mode, you can Uni-cast or Multi-cast data from the serial device server to host computers, and the serial device can also receive data from one or multiple host

Serial Settings | Service Mode | Notification |

port1

Service Mode

UDP Mode

UDP Settings

Listening Port

Multilink

| | Destination Host Begin | Destination Host End | Sending Port | |
|---|--|---|------------------------------------|--|
| 1 | <input type="text" value="192.168.0.1"/> | to <input type="text" value="192.168.0.100"/> | <input type="text" value="10000"/> | <input type="button" value="Auto Scan"/> |
| 2 | <input type="text"/> | to <input type="text"/> | <input type="text"/> | <input type="button" value="Auto Scan"/> |
| 3 | <input type="text"/> | to <input type="text"/> | <input type="text"/> | <input type="button" value="Auto Scan"/> |
| 4 | <input type="text"/> | to <input type="text"/> | <input type="text"/> | <input type="button" value="Auto Scan"/> |

Figure 5-17 UDP mode

Notification

Specify the events that should be noticed. The events can be noticed by E-mail, SNMP trap or system log.




Figure 5-18 Notification

The following table describes the labels in this screen.

| Label | Description |
|-------------------|--|
| DCD changed | When DCD (Data Carrier Detect) signal changes, it indicates that the modem connection status has changed. Notification will be sent. |
| DSR changed | When DSR (Data Set Ready) signal changes, it indicates that the data communication equipment is powered off. A Notification will be sent. |
| CTS changed | When CTS (Clear To Send) signal changes, it indicates that the transmission between computer and DCE can proceed. A notification will be sent. |
| Port connected | In TCP Server Mode, when the device accepts an incoming TCP connection, this event will be trigger. In TCP Client Mode, when the device has connected to the remote host, this event will be trigger. In Virtual COM Mode, Virtual COM is ready to use. A notification will be sent. |
| Port disconnected | In TCP Server/Client Mode, when the device lost the TCP link, this event will be trigger. In Virtual COM Mode, When Virtual COM is not available, this event will be trigger. A notification will be sent. |

Table 5-11 Notification

5.2 Configuration by Web Browser

5.2.1 CONNECT TO THE WEB PAGE


Step 1: Input the IP address of DS with “**https://192.168.10.2**” in the Address input box of IE.

Step 2: Click “**Yes**” button on the dialog box.



Figure 5-19 Certificates

Step 3: Input the name and password, then click "OK".




The dialog box titled "Connect to 192.168.10.2" features a blue header with a question mark and close button. Below the header is a key icon and the text "cgi-bin". The "User name:" field contains a dropdown menu with "admin" selected. The "Password:" field is masked with six dots. A checkbox labeled "Remember my password" is unchecked. At the bottom are "OK" and "Cancel" buttons.

Figure 5-20 Certificates

**Only if password is set.*

Step 4: The system information will be shown as below.



The screenshot shows the "Industrial Device Server" web interface. The header includes the ORing logo and the title "Industrial Device Server". A left sidebar contains a menu with "open all", "Serial Device Server", "System", "Port Serial Setting", "Management", "Save/Reboot", and "Help". The main content area is titled "System Information" and contains a table with the following data:

| | |
|------------------|-------------------|
| IP Address | 192.168.10.2 |
| MAC Address | 00:00:56:04:02:07 |
| Firmware Version | 1.00 |

Figure 5-21 System information



5.2.1.1 System

Time (SNTP)



Figure 5-22 Time (SNTP)

The following table describes the labels in this screen.

| Label | Description |
|-------------|--|
| Name | You can set the name of DS. |
| SNTP | Enable the SNTP server. |
| Time zone | After you set the SNTP enable, select the time zone you located. |
| Time server | Input SNTP server domain name or IP address and Port. |
| Console | Telnet Console (SSH) is included for security reasons. In some cases, you may need to disable this function to prevent unauthorized access from internet. The factory default is enable. |

Table 5-12 Time (SNTP)

IP Configuration

You must assign a valid IP address for DS before attached in your network environment. Your network administrator should provide you with the IP address and related settings. The IP address must be unique and within the network (otherwise, DS will not have a valid connection to the network). You can choose from three possible “**IP configuration**” modes: Static, DHCP/BOOTP. The Factory Default IP address is “**192.168.10.2**”



The screenshot shows the web interface for the ORing Industrial Device Server. The title bar reads "ORing Industrial Device Server". On the left is a navigation menu with the following items: "open all", "Serial Device Server", "System" (expanded), "Time(SNTP)", "IP Configuration", "DDNS Configuration", "User Authentication", "Port Serial Setting", "Management" (expanded), "Save/Reboot", and "Help". The main content area is titled "IP Configuration" and contains a table of settings:

| | |
|-------------------------|---------------|
| IP Configuration | Static |
| IP Address | 192.168.10.2 |
| Netmask | 255.255.255.0 |
| Gateway | 192.168.10.1 |
| DNS Server 1 | 192.168.10.1 |
| DNS Server 2 | |
| Auto IP Report | |
| Auto Report to IP | |
| Auto Report to TCP Port | 0 |
| Auto Report Interval | 0 seconds |

Below the table is an "Apply" button.

Figure 5-23 IP configuration




The following table describes the labels in this screen.

| Label | Description |
|-------------------|--|
| DHCP/BOOTP | Obtain the IP address automatically from DHCP server. |
| Static IP Address | Assigning an IP address manually. |
| Subnet Mask | Set the subnet mask to communicate on the network. |
| Gateway | Enter the IP address of the router in you network. |
| DNS Server | Enter the IP address of the DNS server to translate domain names into IP address. |
| Auto IP Report | The device server will report its status periodically. At DS-Tool->IP collection option show the device server status. The report interval is 0 indicate disable this setting (default). But you can set the other IP or Port. |

Table 5-13 IP configuration

PPPoE setting

PPPoE (Point-to-Point Protocol over Ethernet), Device can use PPPoE mode to connect the Network. Input the “**username**” and “Password”, then click “**Connect**” button. If the device has been connected, the “**Status**” will become the “**Link up**” and device will get an IP address from PPPoE server. Click “Return” button, return the “**IP Configuration**” default page.



Authentication

You can set the password to prevent unauthorized access from network. Input the "Old password" and "New password" to change the password. Factory default is no password.



Figure 5-24 Authentication

5.2.1.2 Port serial setting

Serial configuration



Figure 5-25 Serial configuration



The following table describes the labels in this screen.

| Label | Description |
|------------------------|---|
| Port Alias | Remark the port to hint the connected device. |
| Interface | RS232 |
| Baud rate | 110bps/300bps/1200bps/2400bps/4800bps/9600bps/19200bps/ 38400bps/57600bps/115200bps |
| Data Bits | 5, 6, 7, 8 |
| Stop Bits | 1, 2 (1.5) |
| Parity | No, Even, Odd, Mark, Space |
| Flow Control | No, XON/XOFF, RTS/CTS, DTR/DSR |
| Force TX Interval Time | Force TX interval time is to specify the timeout when no data has been transmitted. When the timeout is reached or TX buffer is full (4K Bytes), the queued data will be sent. 0 means disable. Factory default value is 0. |
| Performance | Throughput: This mode optimized for highest transmission speed. Latency: This mode optimized for shortest response time. |
| Apply | Activate settings on this page. |

Table 5-14 Serial configuration



Port Profile




Figure 5-26 Port Profile

The following table describes the labels in this screen.

| Label | Description |
|--------------------|---|
| Serial to Ethernet | <p>Flush Data Buffer After:</p> <p>The received data will be queued in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flush S2E data buffer" timeout, the data will also be sent. You can set the time from 0 to 65535 seconds.</p> <p>Delimiter:</p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option "Flush Serial to Ethernet data buffer" times out. 0 means disable. Factory default is 0</p> |
| Ethernet to serial | <p>Flush Data Buffer After:</p> <p>The received data will be queued in the buffer until all the delimiters are matched. When the buffer is full (4K Bytes) or after "flush E2S data buffer" timeout, the data will also be sent. You can set the time from 0 to 65535 seconds.</p> |

| | |
|--|--|
| | <p>Delimiter:</p> <p>You can define max. 4 delimiters (00~FF, Hex) for each way. The data will be hold until the delimiters are received or the option “Flush Ethernet to Serial data buffer” times out. 0 means disable. Factory default is 0</p> |
|--|--|

Table 5-15 Port Profile

Service Mode – Virtual COM Mode

In Virtual COM Mode, the driver establishes a transparent connection between host and serial device by mapping the Port of the serial server serial port to local COM port on the host computer. Virtual COM Mode also supports up to 5 simultaneous connections, so that multiple hosts can send or receive data by the same serial device at the same time.



Figure 5-27 Virtual COM mode

The following table describes the labels in this screen.

| Label | Description |
|--------------|---|
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the |



| | |
|----------------|---|
| | connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |

Table 5-16 Virtual COM mode

**Not allowed to mapping Virtual COM from web*

Service Mode – TCP Server Mode

In TCP Server Mode, DS is configured with a unique Port combination on a TCP/IP network. In this case, DS waits passively to be contacted by the device. After the device establishes a connection with the serial device, it can then proceed with data transmission. TCP Server mode also supports up to 5 simultaneous connections, so that multiple device can receive data from the same serial device at the same time.



Figure 5-28 TCP Server Mode

The following table describes the labels in this screen.

| Label | Description |
|-----------------|---|
| TCP Server Port | Set the port number for data transmission. |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Max Connection | The number of Max connection can support simultaneous connections are 5, default values is 1. |

Table 5-17 TCP server mode



Service Mode – TCP Client Mode

In TCP Client Mode, device can establish a TCP connection with server by the method you set (Startup or any character). After the data has been transferred, device can disconnect automatically from the server by using the TCP alive check time or Idle timeout settings.



Figure 5-29 TCP client mode

The following table describes the labels in this screen.


| Label | Description |
|------------------|--|
| Destination Host | Set the IP address of host and the port number of data port. . |
| Idle Timeout | When serial port stops data transmission for a defined period of time (Idle Timeout), the connection will be closed and the port will be freed and try to connect with other hosts. 0 indicate disable this function. Factory default value is 0. If Multilink is configured, only |

| | |
|--------------------------|---|
| | the first host connection is effective for this setting. |
| Alive Check | The serial device will send TCP alive-check package in each defined time interval (Alive Check) to remote host to check the TCP connection. If the TCP connection is not alive, the connection will be closed and the port will be freed. 0 indicate disable this function. Factory default is 0. |
| Connect on Startup | The TCP Client will build TCP connection once the connected serial device is started. |
| Connect on Any Character | The TCP Client will build TCP connection once the connected serial device starts to send data. |

Table 5-18 TCP client mode

Service Mode – UDP Client Mode

Compared to TCP communication, UDP is faster and more efficient. In UDP mode, you can Uni-cast or Multi-cast data from the serial device server to host computers, and the serial device can also receive data from one or multiple host



The screenshot shows the 'Service Mode' configuration page in the ORing Industrial Device Server web interface. The page title is 'Industrial Device Server' and the URL is 'www.oring.com'. The left sidebar contains a navigation menu with the following items: 'open all', 'Serial Device Server', 'System' (with sub-items: Time(SNTP), IP Configuration, DDNS Configuration, User Authentication), 'Port Serial Setting' (with sub-items: Serial Configuration, Port Profile, Service Mode), 'Management' (with sub-items: Save/Reboot, Help), and 'Help'.

The main content area is titled 'Service Mode' and contains the following configuration fields:

- Port: Port1 (dropdown)
- Service Mode: UDP Mode (dropdown)
- Listen Port: (empty text box)
- Host start IP: (empty text box)
- Host end IP: (empty text box)
- Send Port: (empty text box)

Below these fields is a table with 4 rows and 3 columns:

| | Host start IP | Host end IP | Send Port |
|----|----------------------|--------------------------------------|----------------------|
| 1. | <input type="text"/> | <input type="text" value="0.0.0.0"/> | <input type="text"/> |
| 2. | <input type="text"/> | <input type="text" value="0.0.0.0"/> | <input type="text"/> |
| 3. | <input type="text"/> | <input type="text" value="0.0.0.0"/> | <input type="text"/> |
| 4. | <input type="text"/> | <input type="text" value="0.0.0.0"/> | <input type="text"/> |

At the bottom of the configuration area is an 'Apply' button.

Figure 5-30 UDP client mode



5.2.1.3 Management

Access IP Control

Access IP Control Settings allow you to add or block the remote host IP addresses to prevent unauthorized access. If host's IP address is in the accessible IP table, then the host will be allowed to access the DS. You can choose one of the following cases by setting the parameter.

1. Only one host with a special IP address can access the device server, "IP address /255.255.255.255" (e.g., "192.168.0.1/255.255.255.255").
2. Hosts on a specific subnet can access the device server. "IP address/255.255.255.0" (e.g., "192.168.0.2/255.255.255.0")
3. Any host can access the device server. Disable this function by un-checking the "Enable IP Filter" checkbox



Figure 5-31 Access IP

SMTP/SNMP Conf

Email Server configuration includes the mail server's IP address or domain. If the authentication is required, specify your name and password. There are 4 Email addresses that you can specify to receive the notification.

SNMP Server configuration includes the SNMP Trap Server IP address, Community, Location and Contact. There are 4 SNMP addresses you can specify to receive the notification.

SysLog server configuration includes the server IP and server Port. This option need to use with DS-Tool.



The screenshot displays the web interface for the ORing Industrial Device Server. The main content area is titled "SMTP/SNMP Configuration" and is divided into two sections: "E-mail Settings" and "SNMP Trap Server".

E-mail Settings:

- SMTP Server: Port:
- My server requires authentication
- User Name:
- Password:
- E-mail Sender:
- E-mail Address 1:
- E-mail Address 2:
- E-mail Address 3:
- E-mail Address 4:

SNMP Trap Server:

- SNMP Server 1:
- SNMP Server 2:
- SNMP Server 3:
- SNMP Server 4:

The left navigation menu includes the following items:

- open all
- Serial Device Server
- System
 - Time(SNTP)
 - IP Configuration
 - DDNS Configuration
 - User Authentication
- Port Serial Setting
 - Serial Configuration
 - Port Profile
 - Service Mode
- Management
 - Access IP Control
 - SMTP/SNMP Conf.
 - System Event Conf.
 - Save/Reboot
 - Help

Figure 5-32 SMTP / SNMP conf



System Event Conf.

Specify the events that should be notified to the administrator. The events can be alarmed by E-mail, SNMP trap, or system log.



Figure 5-33 SMTP / SNMP conf

The following table describes the labels in this screen.

| Label | Description |
|-----------------------------|--|
| Hardware Reset (Cold Start) | This refers to starting the system from power off (contrast this with warm start). When performing a cold start, DS will automatically issue an Auto warning message by sending E-mail, log information or an SNMP trap after booting. |



| | |
|-----------------------------|--|
| Software Reset (Warm Start) | This refers to restart the computer without turning the power off. When performing a warm start, DS will automatically send an E-mail, log information or SNMP trap after reboot. |
| Login Failed | When an unauthorized access from the Console or Web interface, a notification will be sent. |
| IP Address Changed | When IP address of device changed, a notification will be sent. |
| Password Changed | When password of device changed, a notification will be sent. |
| Access IP Blocked | When the host accesses the device with blocked IP addresses, a notification will be sent. |
| Redundant Power Change | When status of power changed, a notification will be sent. |
| Redundant Ethernet Change | When status of Ethernet port changed, a notification will be sent. |
| DCD changed | When DCD (Data Carrier Detect) signal changes, it indicates that the modem connection status has been changed. A Notification will be sent. |
| DSR changed | When DSR (Data Set Ready) signal changes, it indicates that the data communication equipment is powered off. A Notification will be sent. |
| CTS changed | When CTS (Clear To Send) signal changes, it indicates that the transmission between computer and DCE can proceed. A notification will be sent. |
| Port connected | In TCP Server Mode, when the device accepts an incoming TCP connection, this event will be trigger. In TCP Client Mode, when the device has connected to the remote host, this event will be trigger. In Virtual COM Mode, Virtual COM is ready to use. A notification will be sent. |
| Port disconnected | In TCP Server/Client Mode, when the device lost the TCP link, this event will be trigger. In Virtual COM Mode, When Virtual COM is not available, this event will be trigger. A notification will be sent. |
| Power 1 Fault | When Power 1 Fault, a notification will be sent and the Fault LED will be lighted. |
| Power 2 Fault | When Power 2 Fault, a notification will be sent and Fault LED will be lighted. |



| | |
|---------------|--|
| Eth link down | When Eth link down, a notification will be sent and Fault LED will be lighted. |
|---------------|--|

Table 5-19 System event conf

5.2.1.4 Save/Reboot



Figure 5-34 Save / Reboot

The following table describes the labels in this screen.

| Label | Description |
|-----------------------|---|
| Factory Default | Load default configuration except settings of Network. If you want load all factory default, you should press "Reset" button about the five seconds on the device (Hardware restore). |
| Restore Configuration | Restore the previous exported configuration. |
| Backup Configuration | Export the current configuration to a file. |
| Upgrade Firmware | Upgrade to a new firmware with specified file. |
| Reboot Device | Reboot the device server (warm start). |

Table 5-20 Save / Reboot

5.3 Configuration by SSH Console

5.3.1 Connect to DS

You can use SSH Tool (e.g., PUTTY) to access SSH console of DS. The SSH console interface is shown below.

```

login as: admin
admin@192.168.0.39.'s password:

*****
*** ORING Industrial Serial Device Server Commander ***
*****
-----
[ORING Industrial Serial Device Server Commander]
1. Overview
2. General Settings
3. Network Settings
4. Ports settings
5. Security(Accessible IP) Settings
6. Notification(Auto Warning) Settings
C. Change Password
L. Load Factory Default
S. Save configuration
R. Reboot
Q. Exit & Logout

Select one function (1-6,C,L,S,R,Q): █
  
```

Figure 5-35 SSH



Technical Specifications

| Network Interface | |
|--------------------------|--|
| Ethernet | 10/100Base-T(X) which support Redundant Dual Ethernet or Switch Mode support. Auto-recover less than 10ms |
| connector | RJ-45 |
| Protection | Built-in 1.5KV magnetic isolation |
| Protocols | ICMP, IP, TCP, UDP, DHCP, BOOTP, ARP/RARP, DNS, SNMP MIB II, HTTPS, SSH |
| Serial Interface | |
| Interface | 4x RS232 (IDS-141A) 8x RS232 (IDS-181A) |
| Connector | DB62 Female |
| Serial Baud Rate | 110 bps to 115.2 Kbps |
| Data Bits | 5, 6, 7, 8 |
| Parity | odd, even, none, mark, space |
| Stop Bits | 1, 1.5, 2 |
| RS-232 signals | TxD, RxD, RTS, CTS, DTR, DSR, DCD, GND |
| Flow control | XON/XOFF, RTS/CTS, DTR/DSR |
| Serial Line Protection | Built-in 16KV ESD protection 2KV DC isolation for each port |
| LED Indicators | PWR / Ready: 1) Green On: DC power 1 activated. Green Blinking: System booting / Located by Administrator. ETH Link / ACT: Green ON/Blinking: 10 Mbps Ethernet Green & Amber ON/Blinking: 100 Mbps Ethernet |



| | |
|-----------------------------|---|
| | <p>Serial TX / RX LEDs:</p> <p>Green: Serial port is transmitting / receiving data.</p> <p>Fault: Fault alarm (Amber)</p> |
| Power Requirements | |
| Power Input | PWR1/2: 12~48VDC in 6-pin Terminal Block |
| Reverse Polarity Protection | Present at terminal block |
| Power Consumption | 7 Watts MAX |
| Software Utility | |
| Utility | <p>DS-Tool for Windows NT/2000/XP/ 2003/VISTA which include</p> <p>Device discovery</p> <p>Auto IP report</p> <p>Device setting</p> <p>Access control list</p> <p>Group setting</p> <p>Device monitoring</p> <p>Serial port monitoring</p> <p>Log info</p> <p>Group Firmware update</p> |
| Serial Mode | <p>Virtual Com / TCP Server / TCP Client / UDP /Serial Tunnel</p> <p>TCP Alive Check Timeout</p> <p>Inactivity Timeout</p> <p>Delimiter for Data Packing</p> <p>Force TX Timeout for Data Packing</p> |
| Multiple Link | 5 Hosts simultaneous connection: Virtual Com / TCP server / TCP Client / UDP |
| VCOM Driver | Windows NT/2000/XP/2003/VISTA |
| Configuration | <p>Web HTTPS console, SSH console, Console Command</p> <p>DS-Tool for Windows</p> <p>NT/2000/XP/VISTA</p> |
| Environmental | |



| | |
|-----------------------------|--|
| Operating Temperature | -40~70°C (-40 to 158°F) |
| Operating Humidity | 5% to 95%(Non-condensing) |
| Storage Temperature | -40 to 85°C (-40 to 185°F) |
| Mechanical | |
| Dimensions(W x D x H) | 26.1(W) x 94.9(D) x 144.3(H) mm |
| Casing | IP-30 protection |
| Regulatory Approvals | |
| Shock | IEC 60068-2-27 |
| Free Fall | IEC 60068-2-32 |
| Vibration | IEC 60068-2-6 |
| EMI | FCC Part 15, CISPR (EN55022) class A |
| EMS | EN61000-4-2 (ESD), EN61000-4-3 (RS) EN61000-4-4 (EFT) EN61000-4-5 (Surge) EN61000-4-6 (CS) EN61000-4-8 EN61000-4-11 |
| Warranty | 5 years |