

			37-pin D-type					
[PCI Bus] PIO-48D(PCI) PIO-32DM(PCI)	[ISA Bus] PIO-32/32RL(PC)	[PCI Bus] PI-32L(PCI)H PI-32L(PCI) PI-32B(PCI) PO-32L(PCI)H PO-32L(PCI) PO-32B(PCI) PIO-16/16L(PCI)H PIO-16/16L(PCI) PIO-16/16B(PCI)	[ISA Bus] PIO-16/16TB(PCI) PIO-16/16T(PCI) PIO-16/16RY(PCI) [PC Card] PIO-16/16L(PM) PIO-32D(PM)	[ISA Bus] PI-32L(PC)V PI-32B(PC)H PI-32TB(PC) PI-32T(PC)H PO-32L(PC)V PO-32B(PC)H PO-32TB(PC)	PO-32T(PC)H PIO-16/16L(PC)V PIO-16/16T(PC)H PIO-16/16TB(PC) IRT-16(PC)	[PCI Bus] RRY-32(PCI) RRY-16C(PCI) [PC Card] PIO-24W(PM) [ISA Bus] PI-32RL(PC) PO-32RL(PC) PIO-16/16RL(PC) RRY-32(PC) PRY-32(PC)	[ISA Bus] PIO-24/24(PC) PIO-48W(PC)	
				●				
				●				
	●							
	●							
				●		●	●※1	
				●		●	●※1	
	●							
	●							
				●		●	●※1	
	●							
	●							

Digital I/O

Analog I/O

Counter

Motor Controller

Communication

DIN Rail Adapter

DIN-rail adapter for termination panels

DIN-ADP1



● For use with CM-64(PC)E, CM-32(PC)E, CCB-96

For the detail of accessories, please refer to www.contec.com